




CT01 Flashlight Manual



ThorFire mini zoomable flashlight has three modes: High - Low - Strobe. Fully click the tail switch to turn on/off the light. Half click or tap the tail switch to cycle through modes.



Technical Parameters

1. The light delivers max 150 lumens
2. Runs off one AA or 14500 Battery (Not Included)
3. Size: 3.9 inch (length) * 1.1 inch (Body Diameter)
4. Weight: 2.24 oz (Excluding Battery)
5. Full click tail switch to turn ON/OFF
6. Made of aluminium alloy
7. Adjustable Focus Range: zoom in for an intense beam or out for wider illumination

Operation

Fully click the tail switch to turn on/off the light. Half press or tap the end switch to cycle through modes in order of High-Low-Strobe. Pulling the head to zoom out for wider illumination, pulling back to zoom in for an intense beam.

Battery Usage

1.5V/1.2V AA Battery is usable;
3.7V 14500 Battery is usable.

Battery Replacement

Unscrew the light head to insert the battery with anode(+) toward the light head, screw the light to test.

Usage and Maintenance

- Please do not disassemble the sealed head, doing so can cause damage to the flashlight and will void the warranty.
- High-power light should use battery with high current discharge capability; we suggest using high quality battery to increase the runtime of this high-intensity light.
- Please take out the battery if the flashlight will not be used for a long time, or it may cause damage from electrolyte leakage or battery explosion.
- The O-ring may be worn out after using for a long time. If it happens, please replace the O-ring with a new one to keep the light properly sealed against water.
- Please clean the contacts of your light from time to time, especially if the light flickers or does not light up. There may be several reasons for a flickering or not working light:
Reason A: The battery needs replacing.
Solution: Replace the battery (Please confirm the correct installation of anode and cathode)
Reason B: The threads, PCB board contact or other contacts are dirty.
Solution: Clean the contact points with an alcohol soaked cotton swab. If the above methods don't work, please contact the distributors and refer to the warranty policy.

Product Warranty

We will replace products afflicted with manufacturing defects within 40 days of purchase and repair a light free of charge within 18 months of purchase if problems develop with normal use; if repair is required after 18 months from the date of purchase, we will charge for parts. The total repair fee is dictated by the cost of the replaced materials.

Warning

The led flashlight is a high-intensity lighting device capable of causing eye damage. Avoid shining the light directly into the eyes. For more information, please go to: www.thorfiredirect.com. Any questions or problems, please contact: service@thorfiredirect.com. Facebook page name: ThorFire Official

